

Beam
detection
others look
up to

FFE Ltd. A global innovator in the design and manufacture of world class fire detection solutions.

FFEUK.COM



POCKET GUIDE TO
OPTICAL BEAM DETECTION



THE WORLDS MOST TRUSTED BEAM

CONTENTS

Foreword	04
Glossary of Term	05 - 08
Who should read this guide	09
What is an optical beam smoke detector?	10 - 11
How does optical beam detection work?	12
Types of optical beams available?	13 - 15
How do they differ from others?	16
How should they be installed?	17 - 25

What tools do you need to install it?	26
What are the Maintenance requirements for optical beam smoke detectors?	27
Where can you install them?	28 - 33
When are other detectors more suitable?	34
Further information	35

FOREWORD

The purpose of this guide is to provide information on the correct installation of beam smoke detectors in life-safety and property protection applications. This guide briefly summarizes the principles of operation of beam smoke detectors, their design requirements, and practical applications for their use as a component of a fire alarm system.

Beam smoke detectors can be important components of a well-designed fire alarm system. Their unique capabilities enable beam smoke detectors to overcome many of the problems and limitations of point detectors and aspirating systems in some applications. This guide has been developed to help give you an understanding of the beam smoke detector's capabilities and limitations, and how they differ from point detectors.

Please note that this document is intended only as a general guide to the application of beam detectors. Reference should always be made to the detector manufacturer's installation requirements and instructions, and local standards.

GLOSSARY OF TERMS

ASPIRATING SMOKE DETECTORS

Air is drawn through a network of pipes to detect smoke. Smoke flows into the sampling chamber which detects the presence of smoke particles suspended in air by detecting the light scattered by them in the chamber.

OPTICAL BEAM SMOKE DETECTOR (BEAM)

A fire detector, which uses a beam of light (usually infrared) projected across an open area to monitor for smoke emitted by an incipient fire. There are two basic types of beam detector:

- End-to-End: Transmitter and receiver are mounted at either end of the protected area.
- Reflective: Transmitter and receiver are mounted in the same housing, and the beam is directed at a specially designed reflector, mounted at the opposite end of the protected area.

TRANSMITTER (AKA PROJECTOR, TX)

This device is paired with a dedicated receiver, in an end-to-end beam smoke detector system, which emits the light signal through the area to be protected. The Transmitter can be integrated with the receiver into a single unit.

RECEIVER (AKA SENSOR, RX)

This device is paired with a dedicated transmitter, in a projected beam smoke detector system (End-to-End), which monitors the signal level of the light received after it has passed through the protected area.

CONTROLLER

This is component of an optical beam smoke detector system, that allows the fire alarm engineer or competent person to set-up, configure and fault find the beams at ground level, in replacement of using high level access equipment.

BEAM RANGE

This is the total distance between the beam transmitter and receiver for End-to-End type detectors, and transmitter / receiver to reflector for reflective type detectors.

This is often expressed as 'A to B', where A is the minimum operating range from 0, and the B to the maximum operating range from 0m. For example: 5 to 100m range is a beam that can operate over a distance no less than, 0 to 5m and maximum of 0 to 100m.

DETECTOR COVERAGE

Detector coverage is the area, is simply the width/orbital coverage from the detector in which a fire detector is considered to effectively sense an emerging fire. This area is defined by local and international standards.

DRIFT COMPENSATION

A feature where the detector will automatically adjust position and/or signal transmitted to maintain optimum alignment. This feature is limited to ensure slow developing fires (smouldering fires) are detected whilst mitigating the effects of dirt build up on the detector surfaces and compensate for mild building movement.

PRISM(REFLECTOR)

This component is used on reflective based beams. The highly reflective properties allow it to bounce incoming light back to to the source of the light to a nearby sensor over long distances.

Distances of up to 120m can be achieved with additional prisms set-up in an array.

OBSCURATION

Obscuration is the amount by which a beam of light is reduced by the presence of translucent, non-transparent particles or material in the beams path, normally expressed as a percentage or as dB attenuation.

SENSITIVITY

The ability of a smoke detector to respond to a given level of smoke. This is often an adjustable feature in beam smoke detectors.

POINT DETECTOR

A device, which senses an incipient fire at a single location, most commonly using optical or ionisation smoke detection or heat detection. The area of coverage of a point detector is defined in local or national standards.

STRATIFICATION

The effect which occurs when smoke, which is hotter than the surrounding air, rises until equal to the temperature of the surrounding air, causing the smoke to stop rising.

WHO SHOULD READ THIS GUIDE?

You should read this guide if:

- You specify or design fire detection systems
- You are responsible for your building's fire protection system
- You are the Fire Marshall for your workplace
- You are planning to install a beam smoke detector or other smoke detection system
- You are in a risk assessment role for fire protection
- Your role is to support or sell fire detection systems
- You work in the fire and rescue service

The guide offers general guidance; you should also consult local and national regulations and the manufacturer's technical specifications for particular detectors.

WHAT IS AN OPTICAL BEAM SMOKE DETECTOR?

The most common type of smoke detector is the optical point detector. This contains an infrared light beam projected across a small sensing chamber inside the body of the device. When smoke enters the sensing chamber through the outer holes in the body of the detector, it affects the infrared beam and triggers the device into alarm, alerting individuals present to a fire.

Optical beam smoke detectors work on a similar principle except that the infrared light beam is projected across the open area of a building. This effectively transforms the building into the sensing chamber with the optical beam detecting smoke along the entire beam path.



TUMI-1983 [CC BY-SA 3.0]


Point detector: sensing chamber less than 10 cm long



Beam detector: 'sensing chamber' up to 120m long

HOW DOES OPTICAL BEAM DETECTION WORK?

When smoke passes through the invisible infrared beam, the solid particles and liquid droplets in the smoke reflect and scatter the photons of light. The result is that the intensity of the light is reduced on the far side of the cloud of smoke. This reduction in intensity, known as obscuration, can be detected and used to signal a fire.



The important thing to note is that this effect occurs equally at all points along the beam path, no matter where the smoke passes through the beam, so that the detector behaves effectively as though it was made up of an infinite number of point detectors arranged along a line. This makes optical beam smoke detectors ideal for protecting long distances (up to 120m for a single beam), providing that the beam is completely unobstructed and correctly aligned with the detector.


Did you know?

Infrared light is used in optical beam smoke detectors because it is sensitive across a large range of particles and the beam is invisible to the naked eye, therefore the detectors can operate discreetly in a building.

TYPES OF OPTICAL BEAMS AVAILABLE?

There are two main configurations of optical beam smoke detectors: Reflective and End-to-End. Both consist of a transmitter T (the light source) and receiver R (the detector).

Reflective



End-to-End



Attribute Reflective End-to-End

Installation and maintenance 


Reflective detectors are easier and less expensive to install and maintain than End-to-End detectors, as the electrical cabling is needed on only one side of the protected space, there is only a single device to clean and maintain during servicing.

Alignment 

It is usually easier to align a reflected beam as there is only a single piece of equipment to adjust at one end of the beam (the reflector is usually not adjustable), whereas End-to-End detectors require adjustment at both ends of the beam.

Space required by beam 

The reflected beam diverges as it passes back across the space from the reflector, and so the space needed by the beam is greater. An End-to-End beam can pass through a narrower gap.



HOW DO THEY DIFFER FROM OTHERS?

Point smoke detectors, as their name suggests, detect smoke over very short distances using a chamber inside the detector itself. Some models use the principle of light scattering, where the presence of smoke changes the direction of a light beam so that it is detected by a photodiode. Other models detect a change in the electrical characteristics of the air inside the detector caused by the presence of smoke.

Aspirating smoke detectors draw air into a sensing chamber from an array of sampling points connected via a pipe network. Smoke is detected using similar principles to point smoke detectors.

The most significant difference between these technologies is how the protected area is monitored

HOW SHOULD THEY BE INSTALLED?

RULES FOR INSTALLING OPTICAL BEAM SMOKE DETECTORS


Following the guidelines below will maximise the performance of optical beam detectors and minimise the occurrence of faults and false alarms:



Mount on to solid, structural surfaces: Mount the beam transmitter/receiver/reflector on solid, structural parts of the building which experience minimal movement due to temperature changes, vibration, settling, etc. Use detectors with re-alignment routines to compensate for long-term building movement.



Select the correct beam type for the installation: If the space needing protection is too long for a single beam, consider 'back-to-back', 'face-to-back' or 'face-to-face' arrangements. Alternatively, use detectors equipped with Dynamic Beam Phasing to prevent interference between beams and avoid the need for extra shielding.



Ensure a clear line-of-sight for the beam: Avoid shiny surfaces along the beam path, and preferably keep such surfaces at least a metre from the centre of the beam in reflective detectors (this distance can be lower for End-to-End detectors).



Ensure the beam is aligned: Use detectors with effective alignment indicators or automatic alignment routines to avoid misaligned beams being placed into service.



Arrange beams as needed for optimum coverage of the space: Beams can be crossed without causing spurious signals at receivers.




Avoid direct sunlight: If unavoidable (for example in glass atria), use detectors with light compensation algorithms to adjust for fluctuations in ambient light levels.



Determine appropriate maintenance tasks/intervals: Assess the likely level of optical contamination due to dust or condensation by examining surfaces close to the detector positions. Configure alarm thresholds to suit likely contamination levels. Use detectors with algorithms that monitor and adjust the gain to compensate for slow changes in signal. Schedule maintenance visits to clean optics at appropriate intervals.

Select appropriate system settings: Configure the Delay to Fault settings to suit building operations, for example to allow for brief beam blockages by machinery if this is unavoidable. If operational changes occur regularly, mount a low-level controller to allow easy access for quickly adjusting and optimising settings. Use advanced detectors that monitor trends in beam intensity to separate real fires from other effects.



Take steps to prevent birds from perching on the detectors and possibly blocking the beam (when necessary).



Maintain a system log: Optical beam smoke detectors are life safety devices, and on-site documentation of the installation is vital for recording future maintenance and to assure users of a safe and competent installation.

STANDARD RECOMMENDATIONS (BS 5839 PART 1)


BS 5839 Part 1 gives a code of practice for the design, installation, commissioning and maintenance of automatic fire detection systems in non-domestic buildings. Some of the key recommendations for optical beam smoke detectors are summarised here. This is provided for general guidance only; refer to the standard for detailed information.

HEIGHT OF DETECTORS

Optical beams should be mounted as close to the ceiling to take advantage of the accumulation and spreading of the smoke plume that occurs there during a fire.

The maximum room height that can be protected by a single set of detectors depends on whether or not the ceiling is flat, and also on the sensitivity of the detectors.


Taller spaces require extra or 'supplementary' detection at lower heights (see 'Horizontal Spacing of Detectors').




* Normal sensitivity = detector alarm threshold $>35\%$ attenuation

** Enhanced sensitivity = detector alarm threshold $\leq 35\%$ attenuation; supplementary detection also recommended (see 'Horizontal Spacing of Detectors').

Optical beam smoke detectors can be installed at much greater heights than point detectors (maximum 10.5 m) because the longer length of the protected space offsets the problem of detecting a lower smoke density as the plume disperses.




In some locations, such as in atria or under skylights, it is safer to mount beams close to the maximum distance below the ceiling so they can detect stratified smoke layers that do not reach the ceiling:



DISTANCE FROM VERTICAL SURFACES

Detectors must be at least 0.5m from:


- The nearest vertical wall;
- Any ceiling-mounted surface such as a beam or duct which projects a distance of more than 10% of the total ceiling height;
- Any floor-mounted surface which reaches closer than 300mm to the ceiling.




HORIZONTAL SPACING OF DETECTORS

At ceiling height, the maximum horizontal distance between any point and part of a beam must be 7.5m.


The same limit of 7.5m also applies for point and aspirating smoke detectors, which gives a clear advantage to beams for large areas as the coverage is much more efficient. In the example shown for a floor area of 1260 m², 2 beam detectors are sufficient whereas 12 point detectors or aspirating sampling points are required.



Detectors mounted at the apex of pitched roofs can cover wider horizontal areas due to the “funnelling” effect of the roof. Increase the distance by 1% for every 1° of roof pitch up to a maximum increase of 25% (to give a maximum spacing of 9.38 m):



Supplementary detection is recommended for buildings with very high ceilings. This can provide earlier detection of a fire and avoids the effect of stratification. The horizontal spacing limits are lower than at the ceiling because there is no surface above the protected volume to restrict the dispersion of the smoke plume.



WHAT TOOLS DO YOU NEED TO INSTALL IT?

The instructions for installing, aligning and testing optical beam smoke detectors vary depending on the model and manufacturer and so you should follow the guidance provided with your system. However, the following tools and equipment are useful to have available when installing any type of detection system:



Tools for mounting detectors to building structure: drill, cross-head and flat-head screwdrivers, etc.



Commissioning and test kit: available from your supplier, this contains all the necessary tools to test the detector for fire and fault.



Multimeter and test leads: to check incoming power supply when fault-finding.



Scissor lift or other high-level access equipment: for use when mounting detectors. Access poles are also useful when testing detectors after installation, saving time and avoiding the need to work at height.

WHAT ARE THE MAINTENANCE REQUIREMENTS FOR OPTICAL BEAM SMOKE DETECTORS?

Follow the steps below periodically to maintain the performance of the detectors (the frequency will depend on the cleanliness of the operating environment):

1. Isolate the detectors from the fire alarm control panel.
2. Clean the optical components (transmitter/receiver/reflector) with a soft, lint-free cloth.
3. Re-align the detectors to ensure signal levels are optimal.
4. Reconnect the detectors to the fire alarm control panel.
5. Test the detectors (this usually involves blocking the beam at the receiver).

Did you know?

Some optical beam detectors can be connected to a controller mounted at low level to allow installation and maintenance to be performed without the need for equipment to gain access to the detectors themselves. Certain detectors can also give a signal to inform you when the optics need cleaning.

WHERE CAN YOU INSTALL THEM?

LONG UNOBSTRUCTED DISTANCES

- Warehouses
- Aircraft hangers
- Airport terminals
- Sports centres
- Lift shafts



TALL BUILDINGS

- Manufacturing facilities
- Airport terminals
- Aircraft hangers
- Churches
- Atria



RESTRICTED ACCESS

- Mass transit terminals
- Airport terminals
- Government buildings
- Manufacturing sites




RESTRICTED NUMBERS OF DETECTORS ACCEPTABLE

- Architectural concerns (heritage buildings, modern minimalist styles)
- Ceiling mounting not possible (atria, glass ceilings)
- Open plan offices
- Unobtrusive detection desirable (art galleries, museums, libraries)



EXPLOSIVE ATMOSPHERES

- Electronics can be sealed in explosion proof housings
- Low-level controller located remotely in safe area for system monitoring



Did you know?

Beam smoke detectors are not only able to protect spaces horizontally. They have also been successfully used to protect vertical installations such as lift shafts, where only one or two detectors need to be installed and maintained to protect multiple floors, instead of a much larger number of point detectors.

WHEN ARE OTHER DETECTORS MORE SUITABLE

Certain types of application are not suitable for optical beam smoke detectors:

APPLICATION	REASON	PREFERRED DETECTOR
Highly cluttered areas of restricted space (e.g., roof voids)	Need long unobstructed pathway for beam	Point smoke detectors
Risk of beam blockage (e.g., warehouse racking)	May cause faults/false alarms	Point/aspirating smoke detectors
Lack of structural surfaces for mounting (only cladding/ plasterboard/ wood available)	Beam quickly becomes misaligned and cannot be corrected by automatic re-alignment routines	Point/aspirating smoke detectors
Very dusty environments	Detector optics become coated beyond compensation limits	Flame/heat detectors
Outdoors or in areas with high air flows	Smoke will not predictably accumulate around detectors	Flame detectors

visit: ffeuk.com | +44 (0) 1462 444 740

FURTHER INFORMATION

FFE offers continuous professional development (CPD) training for anyone interested in learning more about the optimal design of optical beam smoke detector networks and how to configure and maintain systems to ensure peak sensitivity for accurate fire detection.

Contact **01462 444740** or email marketing@ffeuk.com for details.